

SL120B Top Fixed

In this short brochure we break down the complete installation process of the Smart-Lock adjustable top fixed channel system

1.

Mark Centre position of the channel and chalk a line



2.

Place channel over the chalked line and mark all the holes



3.

Remove the channel and drill required hole size depending on fixing aplication



4.

Blow all the dust out of the holes to ensure they are clean



5.

Fill the holes with chemical anchor



6.

Set rods into the concrete leaving 15mm protruding out the top of the slab



7.

Place the channel over the top of the threaded rods




8.

install the nuts and washers onto all of the threaded rods



9.

Secure all the nuts using a socket wrench




10. Place all the clamping plates into the channel

NOTE: The number of clamping plates used per panel will determine on the engineering



11.

Install the outside cover with pre-glazed rubbers



12.

Install glass panels into the channel and divide the glass gaps evenly



13.

Using the ratchet spanner or a standard 19mm spanner wind the nuts out untill they touch the side of the channel



14.

Wind out the top nut to tilt the glass forward



15.

Wind out the bottom nut to tilt the glass back.



16.

Using a level check the glass is plumb and make any small adjustments if needed



17.

Install front cover with pre-glazed rubbers.
Push cover down with some force untill the
cover snaps on




18.

Using silicone or glue place a small bead around the end of the channel



19.

Push end cap onto the the channel



20.

Cut the gap rubber to match gap sizes on your project and install them in between the rubber on the covers



Finished Product



SUMMARY

The main key benefits of using our Smart-Lock channel system is it allows you to get a perfect level job every time with very minimal effort

For more information or the complete installation video guide please get in contact with us today.