

SL120S Side Fixed

In this short brochure we break down the complete installation process of the Smart-Lock adjustable side fixed channel system

1.

Mark Centre position of the channel and chalk a line



2.

Place channel over the chalked line and mark all the holes



3.

Remove the channel and drill required hole size depending on fixing aplication



4.

Blow all the dust out of the holes to ensure they are clean



5.

Place channel into position and install concrete screw anchor's



6.

Secure screws using a tourque gun



7. Place all the clamping plates into the channel.

NOTE: The number of clamping plates used per panel will determine on the engineering



8.

Install the outside cover with pre-glazed rubbers




9.

Install glass panels into the channel and divide the glass gaps evenly



10.

Using the ratchet spanner or a standard 19mm spanner wind the nuts out untill they touch the side of the channel



11.

Wind out the top nut to tilt the glass forward



12.

Wind out the bottom nut to tilt the glass back.



13.

Using a level check the glass is plumb and make any small adjustments if needed




Install front cover with pre-glazed rubbers.
Push cover down with some force until the cover snaps on




15.

Using silicone or glue place a small bead around the end of the channel



16.

Push end cap onto the the channel



17.
Cut the gap rubber to match gap sizes on your project and install them in between the rubber on the covers



18.

Make sure rubber is sitting correctly like shown





Finished Product



SUMMARY

The main key benefits of using our Smart-Lock channel system is it allows you to get a perfect level job every time with very minimal effort

For more information or the complete installation video guide please get in contact with us today.